

S 27-38 P

Komponentlista / Component list

Number on draw.	Article Number	Pieces	Benämning	Description
1	17710	2	Chucknyckel	Collet Key
2	27501-38	1	Spindelnos	Spindle Nose
3		2	Främre Kullager	Front Ball Bearing
4	27211	1	Avvisarskiva	Protection Ring
6	S6SS 3x5	2	Skruv	Screw
7	27300-6054 S2C	1	Stator, 189V	Stator, 189V
8	27200-60-38	1	Rotor	Rotor
9	MF6S 8x16	1	Skruv	Screw
10	27400-12	1	Bakre Lagerhållare	Rear Bearing Cage
11	T6SS 3x6	1	Skruv	Screw
12	24,2x3,0	1	O-ring	O-ring
13	27155	1	Stödbricka	Support Washer
13	27155 AC	1	Stödbricka*	Support Washer*
14	27151	1	Ringskruv	Rind Screw
15	27150 P EMC	1	Slutstycke, Tryckluftkyld	End Piece, Air Cooled
15	27150 AC	1	Slutstycke, Vinkelanslutning*	End Piece, Angular Connection*
15	27150 LP-AC	1	Lock, Tryckluftkyld*	Lid, Air Cooled*
16	30160 EMC IM	1	Kontakt, Hane, 6-polig	Contact, Male, 6-pole
16	30160 EMC UM	1	Kontakt, Hane, 6-polig*	Contact, Male, 6-pole*
17	MF6S 3x12	4	Skruv	Screw
17	MC6S 3x8	4	Skruv*	Screw*
18	17571	1	Spännhylsa	Collet
19		1	Avvisarskiva	Deflector Disc
20	27021	1	Skyddsbricka	Protection Ring
21	MC6S 6x50	1	Skruv	Screw
22	27010-38 P	1	Hölje, Tryckluftkyld	Housing, Air Cooled
23		1	Bakre Kullager	Rear Ball Bearing
24	27413	1	Skruv	Screw
25	AZ 6,4	1	Låsbricka	Lockig Washer
26	27412	1	Tätningbricka	Packing Washer
27	SgH 30	1	Segersäkring	Retaining Ring
28	27418	1	Tryckfjäder	Coil Spring
29	MC6S 3x6	1	Skruv	Screw
30	27411	1	Mutter	Nut
31	M6M M6	1	Mutter	Nut